



INSTALLATION

****NOTE: Reflective surface must be flipped prior to installation.**

1. Remove fasteners from frame
2. Flip over reflective surface and remove vinyl cover
3. Secure reflective surface to frame
4. Install using appropriate method

 Coordinate mirror installation with architect and contractor to avoid pipes, vents, wires, etc. in wall. Transfer mounting points to wall surface. Transfer mounting point location to wall surface and drill pilot holes. Secure mirror with proper fasteners per application. Fasteners are not supplied by manufacturer.

To meet ADA Code, bottom edge of reflective surface can be no higher than 40" above finished floor. (4.19.6) Full length mirrors may be used for universal application when installed in correct locations.

CARE & CLEANING

Wipe mirrors with a soft cloth, taking special care to rub stainless steel frames with the grain to avoid scratching. Do not use abrasive cleaners containing chloric solutions on stainless steel frames. Glass Plus or other window cleaning products are ideal.