


B-ClampMounting Instructions



INSTRUCTIONS

- 1. Connect spring to center of clamp
- 2. Insert clamp into rough wall opening and adjust so that clamp grips inside surface of opening.
- 3. Attach back of unit to clamp with mounting screws.