
date projectname attn from fax email phone 4-5-2018 Mission Training Complex Becky


	U128PC Vanity Mounted Soap Dispenser Revision 04/11		JOB #:	
			ITEM #:	
Architectural Products			QUANTITY:	
MOUNTING HANDING	TYPE SIZE	OTHE	R	
SPECIFICATIONS Piston & Spout: Highly polished corrosion resis Assembly rotates 360 degrees. Flange & Collar: One piece highly polished chro Valve Assembly: All purpose bellows valve, fab	102 - 1 2 1/2" 64 mm 13/16" 21 mm 13/16" 21 mm AX 8 1/4" 210 mm AX 8 1/4" 210 mm 4 3 3/8" 86 mm 10 10 10 10 10 10 10 10 10 10	hrough cut out and se Connect supply tube w Secure globe and colla	neter opening in vanity or basin. Insert shank cure with supplied washers and wing nut. <i>vi</i> th valve making sure notch end is at bottom. ar to shank. Fill globe above counter. Secure ink. Prime dispenser every time unit is serviced.	
with stainless steel return spring. Shank: Chrome on brass, secured to collar. Spe unlocks collar for servicing. Globe & Collar: High impact translucent polyeth Capacity: 34 fl oz U128PCA: Same as U128PC with 6" (152mm) s Recommend type soaps without chloric solu operation. *All vanity soap dispensers are designed to b counter	ecial key provided that nylene. spout. tions for proper be serviced above the	"It is not recommended "For best performance Dispensers should hav he life dispenser. Rins sludge buildup. Preventative Maintena Every 30 days with wa	d to mount any soap dispenser on mirrors e, use pre-mixed low concentrate solutions. <i>ve</i> periodic maintenance performed to insure se out globe and valve with warm water to avoid nce: Each dispenser should be flushed out aprx. rm water to prevent valve from clogging with old sive cleaners to clean dispenser.	







	11770	Sorioo		JOB #:
AJVV	U778 Series Surface Mounted Shelf Revision 07/11			ITEM #:
Architectural Products				QUANTITY:
MOUNTING HANDING	TYPE SIZE		OTHER	
MOUNTING HANDING Image: Second state of the se	Il edges are turned down r maximum strength and nooth for safety.	INSTALLATIO Provide an area unit up to wall r	nm	urface at desired or specified location. Place e unit is level. Transfer mounting points oles. Secure shelf to surface with proper ation.
		NOTES		


This information is subject to change without formal notice. If you need additional help, AJW has a technical support staff that is ready to assist you by phone: (845) 562-3332, fax: (845)562-3391, email: engineering@ajw.com or visit our website: www.ajw.com. Copyright © 2013 AJW Architectural Products








email: engineering@ajw.com or visit our website: www.ajw.com. Copyright © 2013 AJW Architectural Products





edges having a radius to prevent injury. Seat is secured to frame with carriage bolts and acorn nuts. Seat is reversible and handing is not required

Tubing: Fabricated of #18 ga stainless steel with #4 satin finish.

Main Frame: 1 1/4" diameter square tubing with capped ends.

Flanges: #18 gauge stainless steel with exposed mounting points. Under slung supports have a 11/4" OD

Supports: #18 ga stainless steel 1 1/4" dia diagonal stainless steel support guides for raising and lowering of seat.

Mounting Bracket: #18 gauge stainless steel "hat" style bracket with four (4) mounting points. Bracket acts as a guide for raising and lowering of seat. For maximum support, bracket is mounted resting on floor absorbing load transfer. Seat will remain in an upright position when not in use by means of a spring clip. Seat has been tested to maintain a 500 lb static load.

Overall Size: 32"W x 20 3/4"D (seating area)

813mm x 514mm


*Wall to floor mounting design provides equal distribution of weight to ensure safe operation.

To comply with ADA Code, seat should be mounted at a height between 17" - 19" above finished floor. Check all state and local codes for building requirements.. Recommend in wall mounting on all shower seats. (BP10) Place seat up against wall making sure the extended part of seat has an offset no more than 1 1/2" away from wall. (Same as grab bar) Transfer mounting points to wall surface and drill pilot holes. Secure seat to surface with proper fasteners for each application. Snugly secure seat to surface and check seat to be level. If seat is level raise and lower seat to check path of travel. Finish securing seat after checking seat for proper operation. When properly mounted seat will support up to 500 lbs and will conform with ADA Code 4.21.3 and 4.26.3, To change handing, remove carriage bolts, switch square length tubing to opposite side and flip deck to change handing and secure with carriage bolts to framing.


Note: This shower seat is not intended to be installed in applications that have shower bases with rounded corners. AJW recommends the U928 for such applications.


NOTES














UX250P Vinyl Shower Curtain Installation & Cleaning Instructions



INSTALLATION

Recommended: UX169 stainless steel shower curtain hooks to connect to AJW shower curtain rods. Various types of flanges are available to secure rod and curtain to mounting surface (exposed and concealed).

Measuring Curtains: Curtains are measured W x H. The same curtain will fit a 1 or 1 1/4" diameter rod.

CARE & CLEANING

Machine wash cold water (not exceeding 41°C / 105°F). Do not bleach. Do not dry clean. Tumble dry low (not exceeding 140°F). Remove promptly.

