date projectname attn from fax email phone 06/27/17 Clear AFS ASRC Construction Sala Sega

tsega@sbsalaska.com 907-261-9257

	114.2	657		JOB #:
AJVV	U136EA Hands Free Soap Dispenser Revision 06/12		ITEM #:	
Architectural Products			QUANTITY:	
MOUNTING HANDING	TYPE SIZE		OTHER	
5 1/2" 139mm 4" 101mm 2" ma 6 3/4" 171mm 2" ma 5 1/2" 2" ma 101mm 2" ma 171mm 171mm 101mm 2" ma 171mm 17	ximum	9 1/8" 231mm INSTALLATIO		
Spour Assembly: Chrome and black plated AE dispenser. Shank Assembly: Black ABS high impact mate diameter in counter top with a maximum thickne included if sink rim is 3/4" high or greater, Electronics: Automatic sensor detects users ha determined amount LED light Indicator for low b capacity. Four (4) D Alkaline batteries self conta counter. Average battery life 100 refills or 2 year Replaceable Containers: Self contained soap contamination, spills and lost service keys. Capacity: Self contained non-refillable bottle w hand washes per bottle, included with unit (lotio Overall Size: 5 1/2"D x 4 1/4"H (above vanity) 140mm x 108mm	erial. Requires a 1" ess of 2". Optional spacer and to dispense a pre- battery and low soap nined motor assembly under rs. refills eliminate cross ith a capacity of aprx, 2000	back of unit to	wall surface teners. Sen o comply wi	e, transfer mounting hole dimensions from a. Drill pilot holes and secure unit to surface usor cannot be any higher than 40" above th ADA code.

















SPECIFICATIONS

Body: Fabricated of #22 ga stainless steel with #4 satin finish. Concealed inner dispensing mechanism is #18 ga stainless steel.

Back: Fabricated of #18 ga stainless steel with multiple welds to cabinet body forming a one piece construction.

Hood: Fabricated of #18 ga stainless steel finished to match cabinet body. Hood is secured with stainless steel hinge rivets to cabinet body. Top roll of tissue will not drop down unless the bottom roll has been depleted. When unit is closed, this will provide a theft resistant, non-control operation and reduce vandalism.

Locks: Pin tumbler, commercial quality locks keyed like all other AJW cabinets.

Spindles: (U005) Fabricated of one-piece molded high impact black ABS material.

Overall Size: 6"W x 12"H x 6 3/4"D

152mm x 305mm x 171mm

Capacity: Two standard rolls with a 5 1/4" (133mm) OD..

INSTALLATION

Provide an area on mounting surface at desired or specified location. Open cabinet, remove spindles and hold unit to wall at desired location. Transfer mounting points and drill pilot holes. Secure unit with proper fasteners per each application. Load toilet tissue on rollers, place in concealed track and close hood. Raise lower roll against upper and take hand away. Lower roll should fall into place with upper roll remaining up above the hood line. If loaded properly, top roll will not fall for use until bottom roll has been depleted. When servicing dispenser, full rolls must be used on both spindles to insure proper operation.

All toilet tissue dispensers that meet ADA code cannot have any type of control delivery. (4.16)

NOTES

Formerly Model #: U840A







SPECIFICATIONS & INSTALLATION

FLANGE INFORMATION

Tubing: Fabricated of #18 ga stainless steel with a #4 satin finish. Available in 1 1/4" outside diameter. All bends are formed by an automatic mandrel bending process. All bars maintain a constant 1 1/2" offset.

Finish: Standard finish is a #4 satin finish. For a non-slip finish (peened) add suffix X to model number. (Ex. UG2X-G)

Flanges: Snap flanges are fabricated of 3" diameter, 3/8" deep drawn #22 ga stainless steel with #4 satin finish to match tubing. Flanges have dimples that secure over mounting plate.

Strength: Bars with a 1 1/2" offset clearance will support loads in excess of 900lbs when properly installed. Bars with greater offsets will support loads up to 250lbs when properly installed.

Installation: Before installing grab bars, verify with all state and local codes for requirements on bar diameter and type finish. Recommended mounting heights for grab bars are 33" - 36" centerline above finished floor. All mounting of grab bars when possible should have in wall mounting back plates. Find centerline mounting points and place bar on line making sure to be on center. Transfer mounting points (3 per flange) to wall. Drill pilot holes and secure bar with proper anchors per application. Snap cover over mounting plate.

Standard Lengths (Other sizes available upon request): 30" x 16", 30" x 18", 36" x 18", 36" x 24", 42" x 36", 54" x 36"

NOTES		









AJW	UX169	JOB #:					
	Shower Curtain Hooks	ITEM #:					
Architectural Products	Revision 03/11	QUANTITY:					
MOUNTING HANDING	TYPE SIZE	OTHER					
378° 278° (3mm) (3mm) </th							
Unit is constructed of stainless steel. Ring sna rod to support curtain. Spacing of hooks is eve installed on both 1" & 1 1/4" diameter rods. Overall Size: 1 3/8"W x 2 7/8 34mm x 73mm	ps around the shower ary 6" and can be NOTES	rrough curtain eyelet. Slide rings onto curtain rod. Hook late 1" & 1 1/4" rods.					

This information is subject to change without formal notice. If you need additional help, AJW has a technical support staff that is ready to assist you by phone: (845) 562-3332, fax: (845)562-3391, email: engineering@ajw.com or visit our website: www.ajw.com. Copyright © 2013 AJW Architectural Products

AJW		171	JO	B #:			
	UX171 Shower Curtain Hooks with Rollers Revision 05/14		ollers	EM #:			
Architectural Products			QL	JANTITY:			
MOUNTING HANDING	TYPE SIZE		OTHER				
2 7/8" (73mm)							
SPECIFICATIONS Unit is constructed of chrome plated steel. F shower rod to support curtain. Spacing of h be installed on both 1" & 1 1/4" diameter rod Overall Size: 1 3/8"W x 2 7/8 34mm x 73mm	Ring snaps around the ooks is every 6" and can ls.	INSTALLATIO Thread hook th can accommod NOTES		yelet. Slide rings onto curtain rod. Hook rods.			





UX250P Vinyl Shower Curtain Installation & Cleaning Instructions



INSTALLATION

Recommended: UX169 stainless steel shower curtain hooks to connect to AJW shower curtain rods. Various types of flanges are available to secure rod and curtain to mounting surface (exposed and concealed).

Measuring Curtains: Curtains are measured W x H. The same curtain will fit a 1 or 1 1/4" diameter rod.

CARE & CLEANING

Machine wash cold water (not exceeding 41°C / 105°F). Do not bleach. Do not dry clean. Tumble dry low (not exceeding 140°F). Remove promptly.