date
projectname
attn
from
fax
email
phone

1 sas saasa 1



U860

Seat Cover, Sanitary Napkin Disposal & Toilet Tissue Dispenser Combination Unit

	JOB #:
	ITEM #:
	QUANTITY:

Revision 03/11

MOUNTING	HANDING	TYPE	SIZE	OTHER	
17 1/4" 438mm 15 1/4" 387mm	12 3/4" 324mm 32 3/4" 832mm 20" 508mm	1/4" 6mm	2 5/8" 68mm 30 3/4" 832mm	57"- 60" (1447mm-1524mm) RECOMMENDED MOUNTING HEIGHT March March	WOOD FILLER (NOT PROVIDED) 2 1/4" 101mm
		_		SM	-S2

SPECIFICATIONS

 $\textbf{Cabinet:} \ \ \textbf{Fabricated} \ \ \text{of \#22 gauge stainless steel.} \ \ \textbf{All exposed surfaces} \\ \ \ \text{have a \#4 satin finish.}$

Flange: Fabricated of #22 gauge stainless steel one-piece drawn seamless construction. No seams or exposed miters with 1/4" returns to wall surface.

Napkin Disposal: Self closing push panel door is fabricated of #22 gauge stainless steel. Removable Waste is fabricated of same material with pin tumbler lock. Waste is identified with International Graphic symbol.

Toilet Tissue Dispenser: #22 gauge stainless steel hat adapters secure chrome plated, spring loaded rollers in place.

U007 Theft Resistant Adapter: Prevents spindle from being removed until roll has been depleted.

Seat Cover Dispenser: #22 gauge stainless steel secured by pin tumbler lock.

Hinges: All hinges are full length, heavy duty, stainless steel piano type hinges.

Collars: #22 ga stainless steel finished to match cabinet.

Overall Size: 17 1/4"W x 32 3/4"H x 4 1/4"D

438mm x 832mm x 108mm

Wall Opening: 15 3/4"W x 31 1/4"H x 4"D

400mm x 793mm x 102mm

U860-S2: 2" semi-recessed. collar, 2" wall opening, 51 mm

U860-SM: Full surface mounted collar. **Waste Capacity:** 2 Gallons (.26 cu ft)

Toilet Tissue: Two standard rolls with a 5 1/4" (133mm) OD.

Seat Cover Capacity: 500

INSTALLATION

Provide rough wall opening at desired or specified location of 15 3/4"W x 31 3/4"H. (Depth of opening will depend on type mounting required.) Place lower unit in opening. Before securing place seat cover dispenser in opening to ensure proper fit. If both units fit properly in opening, secure bottom unit than the top. If collars are required, place collar onto the units from the back before securing to mounting area. Fill seat cover dispenser and toilet tissue rolls.

Toilet Paper Dispensers: All dispensers that are to meet ADA code cannot have any type of controlled delivery. (4.16)

NOTES