

LIABIDING

BACHBITIBIC

U934

Retractable Shower Seat

	JOB #:
	ITEM #:
	QUANTITY:

Revision 1/14

MOUNTING	HANDING	IYPE	SIZE	OTHER
2 1/2" 63mm	18 1/2" 470 mm		18" 457 mm	15" 381 mm 29 mm Spring Clip \$ 12 1/4" 311 mm

SPECIFICATIONS

Seat: Fabricated of 2 1/2" thick water-resistant reinforced vinyl fabric cushion (white) seamless design with all leading edges having a radius. Seat is secured to a 1/2" thick marine plywood.

Tubing: Fabricated of #18 ga stainless steel with #4 satin finish.

Main Frame: Fabricated of #18 ga 1 1/4" with satin finish tubing. Underside has no exposed fasteners.

Flanges: #18 gauge stainless steel with four (4) countersunk exposed mounting points. Under slung supports have a 1 1/4" OD. (Satin finish)

Mounting Bracket: #14 ga stainless steel "hat" style bracket with 4 mounting support points. Bracket acts as a guide to raise and lower seat platform and is equipped with four (4) points to secure to wall surface. For maximum support, bracket is mounted so the bottom is set on the finished floor surface. Seat will remain in an upright position when not in use by means of a spring clip.

Overall Size: 18 1/2"W x 15"D (seating area)

470mm x 381mm

*Wall to floor mounting design provides equal distribution of weight to ensure safe operation.

INSTALLATION

To comply with ADA Code, seat should be mounted at a height 17" -19" above finished floor. Check all state and local codes for building requirements. Recommend in wall mounting on all shower seats. (BP10) Place seat up against wall making sure the extended part of seat has an offset no more than 1 1/2" away from wall. (Same as grab bar) Transfer mounting points to wall surface and drill pilot holes. Secure seat to surface with proper fasteners per each application. Snugly secure seat to surface and check seat to be level. If seat is level raise and lower seat to check path of travel. Finish securing seat after checking seat for proper operation. When properly mounted seat will support up to 250 lbs and will conform with ADA Code 4.21.3 and 4.26.3

Note: This shower seat is not intended to be installed in applications that have shower bases with rounded corners. AJW recommends the U928 for such applications.

NOTES

Formerly Model #: U934-1A