

US130GSECURITY GRAB BAR EXPOSED FLANGE G

| | Job #: |
|--|-----------|
| | Item #: |
| | Quantity: |

| MOUNTING | HANDING | TYPE | SIZE | OTHER | |
|---|----------------------------------|------|-------------------------------------|---|--|
| | | | | | |
| 2 1/6" C/L "A" (CENTER LINE BAR DIMENSION) | #11 GUAGE CLOSURE PLATE (WELDED) | N) | 3" O.D. EXPOSED FLANGE (3) | "B" (CENTER LINE BAR DIMENSION) #11 GUAGE CLOSURE PLATE (WELDED) | 2 1/4" 6" C/L "A" (CENTER LINE BAR DIMENSION) - 1 ½" |
| 1 1/2" | | | | | 1 1/2" |
| LEFT HAI | ND | | | RIG | HT HAND |

SPECIFICATIONS INSTAI

Tubing: Fabricated of type 304 #18 ga stainless steel with a #4 satin finish and 1 1/2" outside diameter. All bends are formed by an automatic mandrel bending process. All bars maintain a constant 1 $\frac{1}{2}$ " offset. Add suffix "X" for peened grip (Nonslip finish) Ex: US130X-G-5436

Flanges: Flanges are fabricated of 3" diameter, type 304 #11 ga stainless steel with #4 satin finish to match tubing. Flanges are heliarc welded to bar to form a one piece construction, with 3 mounting points (1/4" dia.)

Closure Plate: Fabricated of #11 gauge stainless steel welded to the underside of the bar. LH or RH style must be indicated for this type bar.

Strength: Bars that provide a 1 $\frac{1}{2}$ " offset can support loads in excess of 900 lbs when properly installed. Other configurations can support loads of excess of 250 lbs when properly installed. Grab bars must be installed properly to support the loads intended.

Sizes:

Model: A B Qty: Handing:

US130-G _____ x ________

US130-G _____x _____

US130-H _____ x _____ ___

US130-H _____ x _____

*When measuring and ordering grab bars, remember bars are sized centerline to centerline.

*Grab Bars comply with ADA Code 4.26.2

*Non-chloric and non-abrasive cleaners should be used to

INSTALLATION

Before installing grab bars, verify with all state and local codes for requirements on bar diameter and type finish. Recommended mounting heights for grab bars are 33" - 36" centerline above finished floor. All mounting of grab bars when possible should have in wall mounting back plates. Find centerline mounting points and place bar on line making sure to be on center. Transfer mounting points (3 per flange) to wall. Drill pilot holes and secure bar with proper anchors per application.

NOTES